





### How to use this Mounting Template

1.) Follow the ski manufacturers guidelines to determine your 3-Pin Line position.

2.) With a razor knife cut-out the diamond shape named **Pin Line** position.

3.) Align the diamond cut-out with the mark on the ski. Make sure the template is centered on the ski, use tape to hold in place. Use a sharp pointed punch to mark the 4-hole pattern for the toe-piece riser.

4.) Before drilling, determine the Heel Pad position. First, measure the sole of your boot from the middle of the center 3-Pin hole to the back edge of the boot heel. Use that measurement to mark the distance from the 3-Pin Line position mark on the ski to the Heel Pad position.

**(Correct placement of the heel pad will center the climbing wire under your boot heel and allow the lever assembly to be locked behind the Heel Pad for transport.)**

5.) With a razor knife cut-out the diamond shape named **Back Edge of Boot Heel**.

6.) Align the diamond cut-out with the mark on the ski. Make sure the template is centered on the ski, use tape to hold in place. Use a sharp pointed punch to mark the 2-hole pattern for the Heel Pad.

7.) With all holes marked on each ski you can begin drilling. Please continue to follow the binding mounting instructions.

8.) This guideline can be use for this paper template or when using the Voilé Hardwire Mounting Jig. Mounting techniques vary, it is your responsibility to mount the binding correctly. Please contact Voilé if you have any questions.

Monday-Friday  
801.973.8622

[info@voile.com](mailto:info@voile.com)



### How to use this Mounting Template

1.) Follow the ski manufacturers guidelines to determine your 3-Pin Line position.

2.) With a razor knife cut-out the diamond shape named **Pin Line** position.

3.) Align the diamond cut-out with the mark on the ski. Make sure the template is centered on the ski, use tape to hold in place. Use a sharp pointed punch to mark the 4-hole pattern for the toe-piece riser.

4.) Before drilling, determine the Heel Pad position. First, measure the sole of your boot from the middle of the center 3-Pin hole to the back edge of the boot heel. Use that measurement to mark the distance from the 3-Pin Line position mark on the ski to the Heel Pad position.

**(Correct placement of the heel pad will center the climbing wire under your boot heel and allow the lever assembly to be locked behind the Heel Pad for transport.)**

5.) With a razor knife cut-out the diamond shape named **Back Edge of Boot Heel**.

6.) Align the diamond cut-out with the mark on the ski. Make sure the template is centered on the ski, use tape to hold in place. Use a sharp pointed punch to mark the 2-hole pattern for the Heel Pad.

7.) With all holes marked on each ski you can begin drilling. Please continue to follow the binding mounting instructions.

8.) This guideline can be use for this paper template or when using the Voilé Hardwire Mounting Jig. Mounting techniques vary, it is your responsibility to mount the binding correctly. Please contact Voilé if you have any questions.

Monday-Friday  
801.973.8622

[info@voile.com](mailto:info@voile.com)

